Flanged Socket Head Screw



Re.35,

5,621,614

576 5.522.

 $309, 5624, 973, 023 \ 5, 169, 114 \ 5, 255, 884 \ 5, 310, 152$

DES.3

Protected under one or more of these U.S. Patent numbers: 3,291,432 3,589,942 3,724,798 DES 270,689 4,613,109 4,878,645 4,852,842 DES 398,834 5,941,492 5,964,068 6,006,661 6,102,398 6,158,704 6,454,116B1 6,761,276B2 6,806,425B1

LC200WP Wall Mount for Flat Panel Screens up to 32" with up to 200mm VESA Mounting Patterns

O T#1794 LC200WP Wall Plate Lag Screws 200mm VESA Plate Monitor Not Included Monitor Attaching Screws

Determine which type of monitor attaching hardware is required for the monitor as specified by the monitor manufacturer. Various sizes of monitor attaching screws are provided for convenience (See the Hardware List below)

Wood Lag Screws are provided for wood stud installations. For concrete or metal sutds, use the WMAAB3, concrete anchor bolt kit, or WMATB3, toggler bolt kit, and follow the instructions specific to these fasteners.

1. Remove the Flanged Socket Head Screw from the LC200WP Wall Plate. Keep the Washers and Nuts oriented the same for re-assembly. 2. Find a wood stud in the wall. Determine the best possible viewing location for the monitor. Making sure the LC200WP Wall Plate is level, use it as a template to mark and drill three 1/8" pilot holes, 2-3/4" deep. 3. Attach the LC200WP Wall Plate to the wall using the provided Lag Screws.

4. Attach the 200mm VESA Plate to the Monitor using hardware specified by the monitor manufacturer. Additional washers and setscrews have been provided when additional spacers are needed between the monitor and the 200mm VESA Plate.

5. Attach the LC200WP Wall Arm with attached monitor to the LC200WP Wall Plate with the hardware removed in step 1.

6. Check the mount for stability and make sure all the fasteners are secure.

7. Adjust the tension on the swivel and tilt to keep the monitor in the desired viewing position.

8. If the screen is not level, loosen the Monitor Attaching Screws, adjust the monitor and re-tiahten the screws.

Hardware List

#14 x 2-1/2" HWH Lag Screws .			3
5/16-18 x 1-7/8" Flanged SHC Bo	lt		3
5/16-18 Nylock Nuts			3
5/16" Bellville Washers			
5/16" Flat Washers			3
,			
4mm x 25mm Set Screws	4	4mm Hex Nuts	8
5mm x 30mm Set Screws	4	5mm Hex Nuts	8
6mm x 30mm Set Screws	4	6mm Hex Nuts	8
4mm x 12mm Phillips Screws	4	5mm Flat Washers	24
5mm x 12mm Phillips Screws	4	1/4" Flat Washers	12
6mm x 12mm Phillips Screws		,	